



Dimensions

A - Seat Depth - 22" / 56cm B - Seat Height - 19.5" / 50cm C - Arm Height - 25" / 64cm

Features

- Hardwood, softwood and engineered wood products; all joints pinned & glued for uniformity & strength
- Back: 11 or 12 gauge sinuous springs which are engineered to provide lasting comfort and strength
- Seat: 8 gauge sinuous wire springs for superior ride and comfort
- High resilience seat foam for superior durability and comfort
- Back filled with blown fibre
- Chaise styling for ultimate comfort and support in full recline
- Stainless or antique cupholders
- Toggle power mechanism

41040 DELANEY



Dimensions shown as Width x Depth x Height. Specifications are correct at time of printing and are subject to change without notice. LHF - left hand facing RHF - right hand facing IA - inside arm to inside



04 Home Theater Ottoman 44 x 28 x 19" 112 x 71 x 48cm



09 Corner Curve 47 x 47 x 39" 119 x 119 x 99cm



10 Armless Chair 24 x 39 x 39" 61 x 99 x 99cm



26 LHF Sofabed 54" 27 RHF Sofabed 54" 70 x 39 x 39" 178 x 99 x 99cm



30 Armless Recliner 60 Power Armless Recliner 24 x 39 x 39" 61 x 99 x 99cm



31 Wallhugger Recliner Pwr 33 Swivel Rocker Recliner Chair 35 Wallhugger Recliner Chair 39 Power Rocker Recliner 42 x 39 x 39" 107 x 99 x 99cm IA: 23" / 58cm

32 Rocker Recliner Chair



A0 11 Degree Storage 17 x 39 x 36" 43 x 99 x 91cm



46 RHF Recliner Chair 51 Sofa Recliner 47 I HF Recliner Chair 66 RHF Power Recliner 90 x 39 x 39" 67 LHF Power Recliner 229 x 99 x 99cm 34 x 39 x 39"

86 x 99 x 99cm



61 Power Sofa Recliner IA: 73" / 185cm



52 Sofa Recliner, Drop Table 62 Power Sofa Recliner, Drop Table 90 x 39 x 39" 229 x 99 x 99cm IA: 73" / 185cm



53 Loveseat Recliner 63 Loveseat Recliner Power 66 x 39 x 39" 168 x 99 x 99cm IA: 48" / 122cm



Pwr

58 Loveseat Console 68 Loveseat Console Wedge 81 x 39 x 39" 206 x 99 x 99cm



A1 45 Degree Storage Wedge 36 x 37 x 36" 91 x 94 x 91cm



A2 Storage Console 13 x 39 x 36" 33 x 99 x 91cm



How We Measure

Height - measured from the highest point of the back pillow to the floor.

Depth - measured from the front edge of the seat cushion to the top of the back.

Width - measured from the widest point of the arm or arm pillow to the widest point of the opposite arm or arm pillow.

Arm Height - measured from the top of the arm to the floor.

Seat Height - measured from the crown of the seat cushion to the floor.

Warranty

Wood Frames, Springs or Webbing - ten year warranty

Metal Frames - two year warranty under normal household use

Motion Reclining Mechanisms - seven year warranty

Reclining Chairs, Sofabed Mechanisms and Sofabed Mattresses - two year warranty


Seat Cushion Foam and Fibre-filled Components - five year pro-rated warranty

41040 DELANEY




Popular Configurations

Note: Always assemble configurations from right hand facing to left hand facing components.




Configuration MA

106 x 106" 269 x 269cm



Configuration MF

126 x 68" 320 x 173cm



Configuration MB

105 x 118" 267 x 300cm




Configuration MG

166 x 72" 422 x 183cm




Configuration MD

118 x 118" 300 x 300cm



Configuration MH

118 x 64" 300 x 163cm



Configuration ME

166 x 74" 422 x 188cm

122 x 188cm



Configuration MI

155 x 64"

394 x 163cm