



## **Dimensions**

A - Seat Depth - 22" / 56cm B - Seat Height - 19" / 48cm C - Arm Height - 25" / 64cm

## **Features**

- Hardwood, softwood and engineered wood products; all joints pinned & glued for uniformity & strength
- Back: 11 or 12 gauge sinuous springs which are engineered to provide lasting comfort and strength
- Seat: 8 gauge sinuous wire springs for superior ride and comfort
- High resilience seat foam for superior durability and comfort
- Back filled with blown fibre
- Chaise styling for ultimate comfort and support in full recline
- Outside handle mechanism
- Toggle power mechanism

# **41094 REGENT**



Dimensions shown as Width x Depth x Height. Specifications are correct at time of printing and are subject to change without notice. LHF - left hand facing RHF - right hand facing IA - inside arm to inside



03 Loveseat 62 x 39 x 41" 157 x 99 x 104cm IA: 42" / 107cm

33 Swivel Rocker

39 Power Rocker

97 x 99 x 104cm

Recliner Chair

Pwr

Chair

\*\*

Recliner

38 x 39 x 41"

IA: 16" / 41cm



04 Home Theater Ottoman 44 x 28 x 19" 112 x 71 x 48cm



09 Corner Curve 47 x 47 x 41" 119 x 119 x 104cm



10 Armless Chair 23 x 39 x 41" 58 x 99 x 104cm



26 LHF Sofabed 54" 27 RHF Sofabed 54" 70 x 39 x 41" 178 x 99 x 104cm



30 Armless Recliner 60 Power Armless Recliner 23 x 39 x 41" 58 x 99 x 104cm



58 Loveseat Console 68 Loveseat Console

Pwr

75 x 39 x 41" 191 x 99 x 104cm





32 Rocker Recliner Chair 46 RHF Recliner Chair 31 Wallhugger Recliner 47 LHF Recliner Chair 66 RHF Power Recliner 84 x 39 x 41" 67 LHF Power Recliner 213 x 99 x 104cm

31 x 39 x 41" 35 Wallhugger Recliner 79 x 99 x 104cm



61 Power Sofa Recliner Table 62 Power Sofa Recliner, Drop Table IA: 64" / 163cm 84 x 39 x 41" 213 x 99 x 104cm



52 Sofa Recliner, Drop 53 Loveseat Recliner 63 Loveseat Recliner Power 62 x 39 x 41" 157 x 99 x 104cm IA: 42" / 107cm IA: 65" / 165cm



A2 Storage Console 13 x 39 x 36" 33 x 99 x 91cm





A0 11 Degree Storage Wedge Wedge 17 x 39 x 36" 36 x 37 x 36" 43 x 99 x 91cm 91 x 94 x 91cm



## **How We Measure**

**Height** - measured from the highest point of the back pillow to the floor.

**Depth** - measured from the front edge of the seat cushion to the top of the back.

**Width** - measured from the widest point of the arm or arm pillow to the widest point of the opposite arm or arm pillow.

**Arm Height** - measured from the top of the arm to the floor.

**Seat Height** - measured from the crown of the seat cushion to the floor.

## Warranty

**Wood Frames, Springs or Webbing** - ten year warranty

**Metal Frames** - two year warranty under normal household use

**Motion Reclining Mechanisms** - seven year warranty

Reclining Chairs, Sofabed Mechanisms and Sofabed Mattresses - two year warranty


**Seat Cushion Foam and Fibre-filled Components** - five year pro-rated warranty

# **41094 REGENT**




# **Popular Configurations**

Note: Always assemble configurations from right hand facing to left hand facing components.




#### **Configuration MA**

107 x 107" 272 x 272cm



#### **Configuration MF**

124 x 72" 315 x 183cm



#### **Configuration MB**

103 x 121" 262 x 307cm




#### **Configuration MH**

115 x 68" 292 x 173cm




#### **Configuration MD**

116 x 121" 295 x 307cm



#### **Configuration MI**

151 x 68" 384 x 173cm



#### **Configuration ME**

166 x 75" 422 x 191cm