



Dimensions

A - Seat Depth - 21.5" / 55cm B - Seat Height - 19.5" / 50cm C - Arm Height - 26.5" / 67cm

Features

- Hardwood, softwood and engineered wood products; all joints pinned & glued for uniformity & strength
- Back: 11 or 12 gauge sinuous springs which are engineered to provide lasting comfort and strength
- Seat: 8 gauge sinuous wire springs for superior ride and comfort
- High resilience seat foam for superior durability and comfort
- Back filled with blown fibre
- Chaise styling for ultimate comfort and support in full recline
- Outside handle mechanism
- Toggle power mechanism

41098 DURANT



Dimensions shown as Width x Depth x Height. Specifications are correct at time of printing and are subject to change without notice. LHF - left hand facing RHF - right hand facing IA - inside arm to inside



03 Loveseat 66 x 39 x 40" 168 x 99 x 102cm IA: 42" / 107cm



30 Armless Recliner 60 Power Armless Recliner 23 x 39 x 40" 58 x 99 x 102cm



04 Home Theater Ottoman 44 x 28 x 19" 112 x 71 x 48cm

33 Swivel Rocker

39 Power Rocker

107 x 99 x 102cm

Recliner Chair





09 Corner Curve 47 x 47 x 40" 119 x 119 x 102cm



33 x 39 x 40"



10 Armless Chair

58 x 99 x 102cm

23 x 39 x 40"

61 Power Sofa Recliner 66 RHF Power Recliner 88 x 39 x 40" 67 LHF Power Recliner 224 x 99 x 102cm IA: 64" / 163cm



22 Sofabed, Queen, 3 Cushion 90 x 39 x 40" 229 x 99 x 102cm



Table 62 Power Sofa Recliner, Drop Table 88 x 39 x 40" 224 x 99 x 102cm IA: 64" / 163cm



26 LHF Sofabed 54" 27 RHF Sofabed 54" 72 x 39 x 40" 183 x 99 x 102cm



53 Loveseat Recliner 63 Loveseat Recliner Power 66 x 39 x 40" 168 x 99 x 102cm IA: 42" / 107cm



58 Loveseat Console 68 Loveseat Console Pwr

79 x 39 x 40" 201 x 99 x 102cm



Chair

Recliner

42 x 39 x 40"

IA: 18" / 46cm

A0 11 Degree Storage Wedge 17 x 39 x 36" 43 x 99 x 91cm



31 Wallhugger Recliner 47 LHF Recliner Chair

35 Wallhugger Recliner 84 x 99 x 102cm

A1 45 Degree Storage Wedae 36 x 37 x 36" 91 x 94 x 91cm



A2 Storage Console 13 x 39 x 36" 33 x 99 x 91cm



How We Measure

Height - measured from the highest point of the back pillow to the floor.

Depth - measured from the front edge of the seat cushion to the top of the back.

Width - measured from the widest point of the arm or arm pillow to the widest point of the opposite arm or arm pillow.

Arm Height - measured from the top of the arm to the floor.

Seat Height - measured from the crown of the seat cushion to the floor.

Warranty

Wood Frames, Springs or Webbing - ten year warranty

Metal Frames - two year warranty under normal household use

Motion Reclining Mechanisms - seven year warranty

Reclining Chairs, Sofabed Mechanisms and Sofabed Mattresses - two year warranty


Seat Cushion Foam and Fibre-filled Components - five year pro-rated warranty

41098 DURANT




Popular Configurations

Note: Always assemble configurations from right hand facing to left hand facing components.




Configuration MA

106 x 106" 269 x 269cm



Configuration MF

122 x 71" 310 x 180cm



Configuration MB

103 x 122" 262 x 310cm




Configuration MG

162 x 75" 411 x 191cm




Configuration MD

116 x 122" 295 x 310cm



Configuration MH

114 x 67" 290 x 170cm



Configuration ME

164 x 76"

417 x 193cm



Configuration MI

150 x 67"

381 x 170cm