



41920 PACIFICO

Dimensions shown as Width x Depth x Height. Specifications are correct at time of printing and are subject to change without notice.
LHF - left hand facing RHF - right hand facing IA - inside arm to inside arm For SKU options: R=Manual Recline, E=Power Recline



1R Manual Recliner
36 x 39 x 42"
91 x 99 x 107cm
IA: 23" / 58cm




2R LHF Arm, Man
Recliner
30 x 39 x 42"
76 x 99 x 107cm



3R RHF Arm, Man
Recliner
30 x 39 x 42"
76 x 99 x 107cm



4R Armless Loveseat
Man Recl
46 x 39 x 42"
117 x 99 x 107cm



51 Sofa Recliner
83 x 39 x 42"
211 x 99 x 107cm
IA: 70" / 178cm



5R LHF Arm, RHF
Wedge, Man Recl
42 x 39 x 42"
107 x 99 x 107cm
IA: 23" / 58cm



6R RHF Arm, LHF
Wedge, Man Recl
42 x 39 x 42"
107 x 99 x 107cm
IA: 23" / 58cm




7R RHF Wedge, Man
Recliner
36 x 39 x 42"
91 x 99 x 107cm



8R Armless Manual
Recliner
23 x 39 x 42"
58 x 99 x 107cm



9R LHF Wedge, Man
Recliner
36 x 39 x 42"
91 x 99 x 107cm



Dimensions

A - Seat Depth - 22" / 56cm

B - Seat Height - 21" / 53cm

C - Arm Height - 26" / 66cm

Features

- Chaise styling for ultimate comfort and support in full recline
- Hardwood, softwood and engineered wood products; all joints pinned & glued for uniformity & strength
- Back: 11 or 12 gauge sinuous springs which are engineered to provide lasting comfort and strength
- Seat: 8 gauge sinuous wire springs for superior ride and comfort
- Seat Fill - 1.8 lb high resilience foam for superior comfort without loss of support
- Back Fill - Blown fibre back cushions
- Inside Latch for manual operation
- D-pull for manual operation of armless skus
- Toggle Switch for power operation
- LED cupholder switch for power operation
- Touch button for power operation

Options

- Stainless Steel Cupholder
- Antique Cupholder
- Wireless Bass Shaker
- LED cupholder with groundlighting



41920 PACIFICO

Popular Configurations

Note: Always assemble configurations from right hand facing to left hand facing components.

How We Measure

Height - measured from the highest point of the back pillow to the floor.

Depth - measured from the front edge of the seat cushion to the top of the back.

Width - measured from the widest point of the arm or arm pillow to the widest point of the opposite arm or arm pillow.

Arm Height - measured from the top of the arm to the floor.

Seat Height - measured from the crown of the seat cushion to the floor.

Warranty


Wood Frames, Springs or Webbing - ten year warranty

Metal Frames - two year warranty under normal household use

Motion Reclining Mechanisms - seven year warranty

Reclining Chairs, Sofabed Mechanisms and Sofabed Mattresses - two year warranty


Seat Cushion Foam and Fibre-filled Components - five year pro-rated warranty



2 Seats Straight Configuration

66 x 67"


168 x 170cm



2 Seats Curved Configuration

72 x 69"


183 x 175cm



3 Seats Straight Configuration

96 x 67"


244 x 170cm



3 Seats Curved Configuration

107 x 71"


272 x 180cm



4 Seats Straight Configuration

125 x 67"


318 x 170cm



4 Seats Curved Configuration

141 x 76"


358 x 193cm



4 Seats Straight Configuration

119 x 67"


302 x 170cm



2 SEATS STRAIGHT (2_/3_)

59 x 67"


150 x 170cm



3 SEAT STRAIGHT (2_/8_/3_)

83 x 67"

211 x 170cm



4 Seat Curved Configuration

130 x 72"

330 x 183cm