




41059 YALE

Dimensions shown as Width x Depth x Height. Specifications are correct at time of printing and are subject to change without notice.
LHF - left hand facing RHF - right hand facing IA - inside arm to inside



Dimensions

- A - Seat Depth - 22" / 56cm
- B - Seat Height - 19.5" / 50cm
- C - Arm Height - 25" / 64cm

Features

- Hardwood, softwood and engineered wood products; all joints pinned & glued for uniformity & strength
- Back: 11 or 12 gauge sinuous springs which are engineered to provide lasting comfort and strength
- Seat: 8 gauge sinuous wire springs for superior ride and comfort
- High resilience seat foam for superior durability and comfort
- Back filled with blown fibre
- Chaise styling for ultimate comfort and support in full recline
- Toggle power mechanism



09 Corner Curve
45 x 45 x 39"
114 x 114 x 99cm



21 Sofabed, Double
82 x 39 x 39"
208 x 99 x 99cm
IA: 57" / 145cm



32 Rocker Recliner Chair
31 Wallhugger Recliner
Pwr
33 Swivel Rocker
Recliner Chair
35 Wallhugger Recliner
Chair
39 Power Rocker
Recliner
42 x 39 x 39"
107 x 99 x 99cm
IA: 17" / 43cm



49 Cuddler Recliner
Chair
51 x 39 x 39"
130 x 99 x 99cm
IA: 26" / 66cm




56 RHF Chaise
57 LHF Chaise
42 x 64 x 39"
107 x 163 x 99cm



70 Armless Chair
31 x 39 x 39"
79 x 99 x 99cm



72 Armless Wide
Recliner
2P Armless Wide
Recliner Pwr
31 x 39 x 39"
79 x 99 x 99cm



75 Sofa Recliner 2/2
5P Sofa Recliner 2/2 Pwr
84 x 39 x 39"
213 x 99 x 99cm
IA: 57" / 145cm



76 RHF Recliner
6P RHF Wide Recliner
Power
77 LHF Recliner
7P LHF Wide Recliner
Power
42 x 39 x 39"
107 x 99 x 99cm



83 Wedge Seat 22 deg.
27 x 39 x 39"
69 x 99 x 99cm



85 Wedge Seat 45 deg.
54 x 39 x 39"
137 x 99 x 99cm



A4 22 Degree Storage
Wedge
27 x 36 x 36"
69 x 91 x 91cm



41059 YALE

Popular Configurations

Note: Always assemble configurations from right hand facing to left hand facing components.

How We Measure

Height - measured from the highest point of the back pillow to the floor.

Depth - measured from the front edge of the seat cushion to the top of the back.

Width - measured from the widest point of the arm or arm pillow to the widest point of the opposite arm or arm pillow.

Arm Height - measured from the top of the arm to the floor.

Seat Height - measured from the crown of the seat cushion to the floor.

Warranty


Wood Frames, Springs or Webbing - ten year warranty

Metal Frames - two year warranty under normal household use

Motion Reclining Mechanisms - seven year warranty

Reclining Chairs, Sofabed Mechanisms and Sofabed Mattresses - two year warranty


Seat Cushion Foam and Fibre-filled Components - five year pro-rated warranty



2-Seat Angled Wedge Console Reclining Sectional

107 x 46"


272 x 117cm



2-Seat Angled Wedge Reclining Sectional

107 x 47"


272 x 119cm



3-Seat Angled Wedge Reclining Sectional

127 x 58"

323 x 147cm



4-Seat Angled Wedge Reclining Sectional

153 x 77"

389 x 196cm