41099 BOUNTY

PALLISER®
My Home, My Style, My Way™

Dimensions shown as Width x Depth x Height. Specifications are correct at time of printing and are subject to change without notice.
LHF - left hand facing RHF - right hand facing IA - inside arm to inside

32 Rocker Recliner Chair
31 Wallhugger Recliner Pwr
33 Swivel Rocker Recliner Chair
35 Wallhugger Recliner Chair
39 Power Rocker Recliner
29 x 40 x 39"
74 x 102 x 99cm
IA: 22" / 56cm



51 Sofa Recliner
61 Power Sofa Recliner
80 x 40 x 39"
203 x 102 x 99cm
IA: 69" / 175cm



53 Loveseat Recliner
63 Loveseat Recliner Power
57 x 40 x 39"
145 x 102 x 99cm
IA: 46" / 117cm



Dimensions

A - Seat Depth - 22" / 56cm

B - Seat Height - 23" / 58cm

C - Arm Height - 24" / 61cm

Features

- Hardwood, softwood and engineered wood products; all joints pinned & glued for uniformity & strength
- Back: 11 or 12 gauge sinuous springs which are engineered to provide lasting comfort and strength
- Seat: 8 gauge sinuous wire springs for superior ride and comfort
- High resilience seat foam for superior durability and comfort
- Back filled with blown fibre
- Chaise styling for ultimate comfort and support in full recline
- Outside handle mechanism
- Toggle power mechanism

41099 BOUNTY

PALLISER®
My Home, My Style, My Way™

How We Measure

Height - measured from the highest point of the back pillow to the floor.
Depth - measured from the front edge of the seat cushion to the top of the back.
Width - measured from the widest point of the arm or arm pillow to the widest point of the opposite arm or arm pillow.
Arm Height - measured from the top of the arm to the floor.
Seat Height - measured from the crown of the seat cushion to the floor.

Warranty

Wood Frames, Springs or Webbing - ten year warranty
Metal Frames - two year warranty under normal household use
Motion Reclining Mechanisms - seven year warranty
Reclining Chairs, Sofabed Mechanisms and Sofabed Mattresses - two year warranty
Seat Cushion Foam and Fibre-filled Components - five year pro-rated warranty